



# MIESIARKI ZE STAŁĄ DZIEŻĄ



## MIESIARKI EASY

Model	Pojemność dzieży dm <sup>3</sup>	Średnica dzieży cm	Wymiary			Moc kW	Ciężar kg
			szer.	głęb.	wys.		
<b>EASY 50</b>	50	60	67	125	126/160	3,0	354
<b>EASY 80</b>	80	70	77	128	138/171	4,6	392
<b>EASY 120</b>	120	80	87	135	150/182	6,7	590
<b>EASY 160</b>	160	90	97	143	150/184	8,2	626
<b>EASY 200</b>	200	100	107	156	155/191	8,5	723



## MIESIARKI IBT I ITF

Model	Pojemność dzieży dm <sup>3</sup>	Średnica dzieży cm	Wymiary			Moc kW	Ciężar kg
			szer.	głęb.	wys.		
<b>IBT 45</b>	45	53	58	76	136	1,5	320
<b>ITF 80</b>	80	63	69	98	162	2,2	622

### PRZEDSTAWICIELE HANDLOWI:

Region Kraków-Rzeszów tel. 0695 985 225    Region Wrocław-Poznań tel. 0605 744 417  
 Region Katowice-Lódź tel. 0695 985 175    Region Gdańsk-Szczecin tel. 0603 744 497  
 Region Warszawa-Lublin tel. 0603 744 462    Region Olsztyn-Białystok tel. 0695 985 215

# MIESIARKI Z WYJEZDĄ DZIEŻĄ



## PEGASO

Model	Pojemność dzieży dm <sup>3</sup>	Średnica dzieży cm	Wymiary			Moc kW	Ciężar kg
			szer.	głęb.	wys.		
<b>PEGASO 200</b>	200	80	101	160	152/195	7,4	900
<b>PEGASO 260</b>	260	90	101	170	152/195	7,4	950
<b>PEGASO 340</b>	340	100	112	187	163/208	9,4	1080
<b>PEGASO 400</b>	400	100	112	187	163/216	9,4	1150
<b>PEGASO 480</b>	480	110	123	201	164/217	14,0	1250



## IBTE

Model	Pojemność dzieży dm <sup>3</sup>	Wymiary			Moc kW	Ciężar kg
		szer.	głęb.	wys.		
<b>IBTE 120</b>	170	89	122	169	2,6	890
<b>IBTE 160</b>	235	103	140	179	3,3	1240
<b>IBTE 200</b>	340	110	136	220	4,8	1495
<b>IBTE 300</b>	505	121	181	227	6,0	2050
<b>IBTE 300E</b>	505	123	181	227	6,0	2100



### PRZEDSTAWICIELE HANDLOWI:

Region Kraków-Rzeszów tel. 0695 985 225    Region Wrocław-Poznań tel. 0605 744 417  
 Region Katowice-Łódź tel. 0695 985 175    Region Gdańsk-Szczecin tel. 0603 744 497  
 Region Warszawa-Lublin tel. 0603 744 462    Region Olsztyn-Białystok tel. 0695 985 215